

# Michigan Maple Block Company

Petoskey, Michigan

## ASSEMBLY INSTRUCTIONS FOR WOODEN UNDERSHELF

Congratulations on your selection of this solid Maple Hardwood Table and Wooden Undersheff. Great care in the selection of materials and craftsmanship have gone into the manufacturing of this table for you. The table's rich appearance, distinctive grains, character marks and color variations are the purest expressions of nature. Just as no two trees are alike, no piece of wood in the fabrication of this quality table and undersheff looks exactly like another. No man-made material can duplicate hardwood's variety, natural integrity and authenticity.

Parts: Wooden Undersheff

Hardware: 4 - 1/4" x 1-3/4" Lag Bolts  
4 - 1/4" Flat Washers

Tools Required: Drill with a 3/16" wood drill bit  
7/16" Wrench  
Ruler or Tape Measure

Instructions: The undersheff has been designed to fit the legs at approximately 6" above the floor. ***Legs must be installed prior to drilling***

- 1) Measure from the floor level up approximately 6" on the inside of the legs and mark in the center of the leg for the hole to be drilled. (See sketch below).
- 2) With a 3/16" wood drill bit, drill a hole to a depth about 1" into the leg. Drill all 4 legs.
- 3) Position the undersheff between the legs and start one of the 1/4" x 1-3/4" lag bolts with washer at each hole. (Applying bar soap to the lag threads will make them much easier to insert).
- 4) Tighten the lag bolts with a 7/16" wrench securely but do not over tighten.

